

PRODUCT DATA SHEET



NOMAD cold chain shipper with digital thermometer

Product code: VPU2-1586

Unique cutting edge vacuum/PU insulation Technology, developed and patented by the Cool Ice Box Company, offers the medical and food cold chain industries critical protection and thermal stability over a range of ambient temperatures from +43° to -25°. VPU2-1586 can hold temperature sensitive products, between +2° and +8° for about 60 hours in an ambient temperature of 35°. A large range of PCM Refrigerant options are available to meet cold life and holding temperatures required.	NO ^M AD.
Usable cold space capacity / external dimensions	116L – 48.8 x 48.8 cm / 66 x 66 x 66 cm
Internal dimensions	158L – 54 x 54 x 54 cm
Weight including HTBH and PCM packs / excluding	47kg / 20kg
Refrigerant dimensions	PCM+5, HTBH-530 Pink /6 pcs. 36.5 x 36.5 x 2.6 cm, 4.5 kg, Total 27 kg
Cold life from when lid closed to 8°	At +35° Ambient: Approximately 60 hours. (PCM +5°)
External cover	Polyester 1680D, 5mm PE Foam, 2mm aluminised PE foam inner with fabric hinge and #10 closing zip fastener
Shipper box	Hard laminated impact and stain resistant outer and inner cover panels
VPU insulation	60 mm Polyurethane rigid closed cell foam moulding, encapsulating 6 x VIP panels
VIP panel thermal conductivity / Panel thermal resistivity (R-value)	< 0.0035 W/m.K / > 6.0 m2K/W
Packing dimensions	71 x 71 x 71cm, 1pc per carton.
Digital thermometer	TPM-30 digital temperature display
35 30 25 20 15 10 5 6 12 18 24 30 36 42 48 54 60 66 72 78 84 90 96 102 108 114 Hours	Notes: This product contains no lead, mercury, cadmium, hexavalent chromium, polybromobiphenyls (PBB) or polybromodipphenylethers (PBDE) or benzene components. Cold Life will be affected by ambient temperature, direct sunlight, volume and density of contents, temperature of payload on loading, opening the lid of the box, and incorrect conditioning of the PCM cold packs.

The Cool Ice Box Company Ltd.

27 Broad St, South Molton, Devon EX36 3AQ UK Office no: 0845 565 1770 / 0843 277 7770 European Office: 00 33 (0) 553836230

www.coolicebox.com info@coolicebox.com NOMAD is the TM of The Cool Ice Box Company Ltd. Registered Address: 13 Mill Street Bideford, Devon EX39 2JJ